

Patchbar 1

Fig.7 Example Stacking with Patchbar

Fig.7 Beispiel Stapeln mit Patchbar




Fig.7


1 x PCB


2 x IC DIP SOCKET 16 LEGS (100pF inside)

6 x HEADER MALE 2 LEGS

2 x STACKING HEADER SET ARDUINO SHIELD


2 x CD74HC4051








2 x PCB 3 x STACKING HEADER SET ARDUINO SHIELD







IC1 and IC2 (HC4051) are 8 channel bidirectional multiplexers in high speed technology (Typ. $t_{Pd} = 15$ ns). The analogue operating range is $V_{SS} - VEE$. For operation as a digital multiplexer also, VEE is connected to ground (GND). High Signal on \overline{E} disable the switches.

IC1 und IC2 (HC4051) sind schnelle, achtkanalige bidirektionale Multiplexer (Typ. $t_{Pd}=15$ ns). Der Messbereich ist V_{SS} – VEE. Zur Nutzung von binären Signalen wird VEE auf Masse verdrahtet (GND). Mit High Signal auf \bar{E} kann die Messung verhindert werden.




Fig.1

Fig.2 shows simplified how it works.

Die Arbeitsweise ist vereinfacht in Fig.2 dargestellt.

MUX (Selector)			
S2	S1	20	Input Output
0	0	0	0
0	0	1	1
0	1	0	2
0	1	1	3
1	0	0	4
1	0	1	5
1	1	0	6
1	1	1	7





Fig.2

Fig.3 shows the input network.

Fig.3 zeigt die Eingangsbeschaltung.






Fig.4 shows an example for interconection between Arduinos and AINSHIELDS.

Fig.4 zeigt ein Beispiel wie Arduinos und AINSHIELDS miteinander verbunden werden können.